

MRS – IMRC 2015 Conference, Aug. 16-20, 2015

Essence and Mechanism for Rhombohedral Hybrid Bandgap Engineering

Sang H. Choi, Ph.D
Adam J. Duzik*, Ph.D



Advanced Materials and Processing Branch
NASA Langley Research Center
Hampton, VA 23681

*National Institute of Aerospace




Today's Semiconductor Bandgap Engineering

- Currently, major semiconductor alloy epitaxial growth is divided into two material groups.
 - **Cubic:**
 - Diamond structures: group IV semiconductors (Si, Ge, C)
 - Cubic zinc-blende structures: group III-V semiconductors (GaAs, InP), group II-VI semiconductors (ZnSe, CdTe)
 - **Hexagonal:**
 - Wurtzite structures: III-Nitride semiconductors (GaN, AlN, InN)
 - II-VI semiconductor: Zinc-Oxide
 - Hexagonal SiC (2H, 4H)
- The mixture of different crystal structures was thought to be very difficult. We developed a new growth technology of “**Super Hetero Epitaxy**” with SiGeC alloy in which each layer can have different materials and different crystal lattice structures.






Epitaxy Technology




Cubic Zinc-Blende




Cubic Diamond


- Homo Epitaxy: One on One with same crystal structure
- Hetero Epitaxy: One on Different but same crystal structure
- Super-Hetero Epitaxy: One on Different with Different crystal structure



[111]-oriented Cubic Zinc-Blende





Trigonal Sapphire



Wurtzite Structure




Crystal Symmetry Relations




New Rhombohedral Epitaxy Technology

(c) Cubic Rhombohedron Trigonal





||



Cubic Tetragonal Orthorhombic

Conventional Cubic Epitaxy Technology



New Rhombohedral SiGe on c-Sapphire





Cubic crystal also belongs to the Trigonal crystal group by the symmetry. A fundamental cross-structural epitaxy can be established beyond an accidental coincidence lattice matching!



New Super Hetero Epitaxial Technology for Hybrid Crystal Growth




2" SiGe on Trigonal Substrate



Twin Crystal to Each Other




2" SiGe on c-Sapphire Samples






6" SiGe on c-Sapphire Samples




6-inch





4-inch



2-inch




XRD Integral Twin Density Measurement





Single Crystalline SiGe Atomic Layers on Sapphire




NASA patented XRD methods, materials, and fabrication processes.
(US Patent # 7341883, 7558371, 7769135, 7906358, 8226767 and more.)





Epitaxial Relationship with Three Space Symmetry Groups


Inter-Crystal-Lattice Epitaxial Relation


Three different crystals can be integrated into one continuous epitaxial structure.



Substrate  Epitaxial Layer : No Double Position Defect



Substrate  Epitaxial Layer : Double Position Defect at Stepped Interface

 Twin detection XRD works

 Twin detection XRD does not work




New Rhombohedral Semiconductor Epitaxy





Cubic

Multi-Trillion \$ Since 1947



Hexagonal

Multi-Billion \$ Since 1990




Rhombohedral

Rhombohedral Hybrid
Band-gap Engineering
Diagram
Application & Market Size??
Unknown Yet




Epitaxial Layer Growth Optimization


SEM: Unstable island growth




Stable layer-by-layer growth




AFM: Triangular Crystal Planes of SiGe (Atomic Steps), Smooth Surface with 2.2nm Roughness




10µm x 10µm Image
RMS Roughness = 2.24nm







5µm x 5µm Image
RMS Roughness = 1.87nm



1µm x 1µm Image
RMS Roughness = 1.06nm




High Resolution Cross-sectional SEM Image of SiGe on c-Sapphire





TEM Image of Rhombohedral-Trigonal Super Structure




SiGe (111)

Sapphire (0001)




Misfit Dislocation – from SK Hynix





- growth direction: $[111]_{\text{SiGe}} // [0001]_{\text{Al}_2\text{O}_3}$, $[1-10]_{\text{SiGe}} // [11-20]_{\text{Al}_2\text{O}_3}$
- 9 misfit dislocation in ~ 11 nm SiGe range (measured)

- Misfit dislocations are confined at Sapphire-SiGe interface only.
- Device does not use Sapphire area. Therefore misfit dislocations do not harm device.



Residual Twin Defects – from SK Hynix




- Sample #SG715 has 0.7% twin and Sample #SG2-007 has 3% twin defects.
- TEM images show that our samples have residual defects, micro-twins and stacking fault columns. These defects can be eliminated with better surface cleaning and preparation and initial nucleation layer control.




Oval Defect Control

Nomarsky Differential Interference Contrast Microscope Images



Sample with oval defects (splash)




Good Sample (No Oval Defects)

Oval defects can be eliminated with hot-lip effusion cells and better growth control



AFM Measurement – from SK Hynix



- Best RMS roughness = 2.5 nm
- The World's first epitaxy technology to use triangular crystal planes.
- Bridges between cubic semiconductors and trigonal crystals such as piezo-electric, ferroelectric, and non-linear optical crystals.




Comparison of Etch-Pit Densities

Threading Dislocation Pit Density after Secco Etching

IBM's SiGe

SiGe on Si substrate Si(100)

35 % Ge




- ❖ TDP density : $3.90 \times 10^4/\text{cm}^2$
- ❖ LD density : $1.73 \times 10^4/\text{cm}$
- ❖ Cross-hatch pattern

NASA Langley's SiGe

SiGe on sapphire substrate
Sapphire(0001)


78 % Ge



- ❖ TDP density : $1.9 \times 10^2/\text{cm}^2$
- ❖ LD density : 0/cm
- ❖ No Cross-hatch pattern


The surface was etched by using Secco Etchant for 3 seconds.

(Etch rate: 25nm/sec)




Hole (p-type) Mobility of SiGe


500% Faster Than Silicon (Si=105 vs. SiGe=532)



P-type Silicon's Mobility vs. Doping




P-type Germanium's Mobility vs. Doping




Electron (n-type) Mobility of SiGe

280% Faster Than Silicon (Si=220 vs. SiGe=616)



Jacoboni, C., C. Canali, G. Ottaviani, and A. A. Quaranta,
Solid State Electron. 20, 2(1977) 77-89.

220 $\text{cm}^2/\text{V}\cdot\text{s}$ at $1.5 \times 10^{18}/\text{cm}^3$ doping




Fistul V. I., M. I. Iglitsyn, and E. M. Omelyanovskii,
Sov. Phys. Solid State 4, 4 (1962) 784-785.

780 $\text{cm}^2/\text{V}\cdot\text{s}$ at $1.5 \times 10^{18}/\text{cm}^3$ doping

Note: Our Thin Rhombohedral SiGe Sample#2 has **616 $\text{cm}^2/\text{V}\cdot\text{s}$** at $1.5 \times 10^{18}/\text{cm}^3$ doping which is **2.8 times higher electron mobility** than single crystalline Silicon wafer at the sample doping level. **μ_{SiGe} is 2.8 times higher than μ_{Si}**



Super Hetero Crystal Growth Chamber




- About \$1 Million was invested to build the super hetero-crystal crystal growth chamber.
- Additional financial support was made from Department of Transportation (DoT).
- The system can accept standard 2"-6" wafers with a load-lock.
- The system is ready for full computer control.









Functions of Super Growth Chamber



6" Wafer Heater

6-Cell E-Beam Evaporator




RHEED Monitoring

LEED Monitoring




Atomic Precision In-Situ Growth Monitoring

RHEED Patterns Obtained from Sapphire (0001) Surface





$[2\bar{1}\bar{1}0]$ Direction



$[1\bar{1}00]$ Direction



RHEED Pattern of SiGe Epi-Layer



RHEED Pattern of SiGe Epitaxial Layer


- Fuzzy lines are due to 60Hz noise from AC current substrate heater.





Atomic Precision Substrate Surface Monitoring

Low Energy Electron Diffraction (LEED)

- Three bright spots and three deamed spots indicate the atomic surface of trigonal symmetry. The substrate temperature and gas condition change many LEED patterns as different surface reconstructions occur.




100eV LEED Pattern






Toward The World's Best Solar Cell

The World's Highest Efficiency Solar Cell: III-V Multi-Junction Cells on Ge/Si Wafer (44%)



III-V Multi-Junction Solar Cell On Germanium Solar Cell Wafer



Commercial 6" Germanium Wafer is about \$3,000.

NASA's new technology can make 6" SiGe/Sapphire under \$300.

Our SiGe on Sapphire uses transparent substrate: It can receive light in both sides.

Our Goal: 40% Efficiency with 1/10th of price.



Summary

- Rhombohedral super-hetero-crystal epitaxy technology was invented. The world's first triangular crystal-plane epitaxy technology can combine cubic semiconductors with trigonal crystals.
- Germanium-rich single crystal SiGe layers on c-Sapphire can be fabricated with high reliability (>99.9% single-crystal).
- Technology has been patented: US Patents: #8,257,491. #8,226,767. #7,906,358. #7,769,135. #7,558,371. #7,514,726.
- Super growth chamber was designed and manufactured to fabricate highly sophisticated quantum well solar cells and devices.
- Characterization shows single-crystalline SiGe layers on c-Sapphire with some residual defects. Surface morphologies are being improved with the reduction of RMS roughness. Quality is being improved with the reduction of residual defects.
- Technology expansion to III-V, III-Nitride and II-VI is underway.